

2600 Series Stud Installation



Stud Installation Instructions

1
Quarter Turn
Fasteners

Installation Dimensions	Accessories	Materials / Finish	Part No.						
<p>Stud Without Retaining Washer, Retention Type</p> <p style="text-align: center;"> <table border="1"> <tr> <td>P</td> <td>D</td> </tr> <tr> <td>0,60 - 1,65</td> <td>Ø 6,5 + 0,2</td> </tr> <tr> <td>1,65 - 3,20</td> <td>Ø 7,1 + 0,2</td> </tr> </table> </p> <p>4P3 installation pliers, see page 24</p>	P	D	0,60 - 1,65	Ø 6,5 + 0,2	1,65 - 3,20	Ø 7,1 + 0,2	-	-	-
P	D								
0,60 - 1,65	Ø 6,5 + 0,2								
1,65 - 3,20	Ø 7,1 + 0,2								
<p>Stud With Retaining Washer, Floating Type</p> <p style="text-align: center;"> <table border="1"> <tr> <td>P</td> <td>D</td> </tr> <tr> <td>0,60 - 1,65</td> <td>Ø 6,5 + 0,2</td> </tr> <tr> <td>1,65 - 3,20</td> <td>Ø 7,1 + 0,2</td> </tr> </table> </p> <p>4P3 installation pliers, see page 24 Retaining washer installation: See page 5</p>	P	D	0,60 - 1,65	Ø 6,5 + 0,2	1,65 - 3,20	Ø 7,1 + 0,2	Retaining washer	Stainless steel / passivated	2600-SW
P	D								
0,60 - 1,65	Ø 6,5 + 0,2								
1,65 - 3,20	Ø 7,1 + 0,2								
<p>Stud With Retaining Washer, Fixed Spring Cup</p> <p>* P max. = 4.75</p> <p>Installation: See page 5 Installation tool T98-1, See page 24</p> <p>4P3 installation pliers, see page 24</p>	Retaining washer	Stainless steel / not for passivated chrome finishes	V2600-LW-7						
<p>Sealed</p> <p>Installation: See page 5 Installation tool T98-1, See page 24</p> <p>4P3 installation pliers, see page 24</p>	Gaskets	Rubber (100°C)	AN6227-B6						
		Rubber (100°C)	AN6227-B3						

ISSUE 3 250609

T: + 44 (0)1803 868677 • F: + 44 (0)1803 868678

E: sales@specialty-fasteners.co.uk

W: www.specialty-fasteners.co.uk

**SPECIALTY
FASTENERS &
COMPONENTS LTD**

23 QT

Stud Installation Instructions

Installation Instructions	Accessories	Materials / Finish	Part No.
<p>Stud Without Retaining Washer, Retention Type</p> <p>* P = 0.5 - 3.2 4P3 installation pliers see below.</p>	-	-	-
<p>Stud With Retaining Washer, Floating Type</p> <p>Retaining washer Installation: See page 5</p> <p>4P3 installation pliers see below.</p>	Retaining washer	Stainless steel / passivated	2600-SW
<p>Stud With Retaining Washer, Fixed Spring Cup</p> <p>Retaining washer Installation: See page 5</p> <p>4P3 installation pliers Installation: See page 5</p> <p>Installation tool see below</p>	Retaining washer	Stainless steel / passivated	V2600-LW-7
<p>Retaining washer</p> <p>Retaining washer</p> <p>Steel / zinc-plated, CrVI free, clear passivated</p>			V27W01-1AN
	Stud installation pliers		4P3
	V2600-LW-7 retaining washer installation tool		T98-1

ISSUE 3 250609

Receptacle Installation Instructions

Installation Dimensions	
Type 1 + 3 Receptacles Hole Pattern 	Type 2 Receptacles Hole Pattern (Side Mounting)

Installation Dimensions	Accessories	Materials / Finish	Part No.
Type 5 Installation Hole 	Retaining nut Tap 	Steel / zinc-plated, CrVI free, clear passivated	99N10-01A1 15/32-32NS-2B